

# Appendix C

## Front Panel

This appendix displays the front panel of all switches covered by this guide.

Figure C-1: DCS-7160-32CQ




Figure C-2: DCS-7160-48YC6




Figure C-3: DCS-7160-48TC6




Figure C-4: DCS-7170-32C




Figure C-5: DCS-7170-32CD

